

EBERSPÄCHER AIRTRONIC M3 D4L SPARE PARTS MANUAL



This spare parts list is valid for the following engine-independent air heaters:

Air heaters for diesel fuel

	Order No.
Airtronic M3 D4L 12 V	25.2955.05.0000
Airtronic M3 D4L 12 V VDP	25.3035.05.0000
Airtronic M3 D4L 24 V	25.2956.05.0000
Airtronic M3 D4L 24 V	25.3039.05.0000
Airtronic M3 D4L 24 V ADR	25.2957.05.0000
Airtronic M3 D4R 12 V	25.3036.05.0000
Airtronic M3 D4R 12 V VDP	25.3051.05.0000
Airtronic M3 D4R 12 V CI-Bus	25.3101.05.0000
Airtronic M3 D4R 12 V* CI-Bus	25.2958.05.0000
Airtronic M3 D4R 24 V	

*) Cable outlet, left

Air heaters for petrol

	Order No.
Airtronic M3 B4L 12 V	20.2030.05.0000
Airtronic M3 B4R 12 V	20.2031.05.0000

Identify the correct service components for the Airtronic M3 (Commercial and Recreational variants) with this official spare parts catalogue. Featuring detailed exploded view drawings and manufacturing part numbers, this document facilitates accurate selection of spares for the maintenance of the Airtronic 3 generation heater.

1 Information

1.1 General information

This document is to be used when ordering spare parts for the heaters listed on the title page, to the exclusion of all liability claims.

Depending on the version or revision status of the heater, differences may occur compared to this documentation. Please check this before ordering the spare parts and take any possible differences into account.

1.2 Reference documents

Technical description

Describes the function and proper installation and contains all information necessary for safe operation of the heater.

Repair instructions

Contain the necessary information for troubleshooting and for repair of the heater.

Installation recommendation

Describes vehicle-specific installation situations.

Installation Instructions Plus

Supplementary information on heaters and control units.

1.3 Determining the quantity required for the order

The information in the “quantity per unit” and “quantity per SU” (sales unit) columns is used to determine the quantity of a spare part required and the SU (sales units) to be ordered.

Quantity per unit

The number in this column indicates how many of the spare part concerned are installed in the whole unit.

Quantity per SU

The number in this column indicates how many of the spare part concerned are contained in one SU (sales unit).

Order No. (SU)

The order number refers to an SU.

1.4 Using the nameplate to determine the production date

To place the spare parts order correctly, in some cases it is necessary to determine the production date of the heater before ordering the spare part. There are two options for doing this on the heater's nameplate.



1 Determination of the calendar week

- Representation of the production calendar week as a four-digit number (e.g. “1118” = calendar week 11 in year 2018)


2 Determining the date

- Scan the QR code with a QR code reader.
- The production date is given by the 8-digit representation of the date in the third from last position of the read out text (e.g. “14032018” = 14 March 2018)

2 Heater

2.1 Spare parts diagram

2.1.1 Airtronic M3



2.2 Spare parts list


Item No.	Quantity per unit	Quantity per SU	Designation	Order No. (SU)	For unit																					
					D2L, 12 V	D2L, 12 V	D2L, 12 V CI	D2L, 12 V CI	D2L, 12 V VDP	D2L, 24 V	D2L, 24 V ADR	D4L, 12 V	D4L, 12 V VDP	D4L, 24 V	D4L, 24 V ADR	D4R, 12 V	D4R, 12 V VDP	D4R, 12 V CI	D4R, 12 V CI	D4R, 24 V	D6L, 12 V	D6L, 12 V VDP	D6L, 24 V	D8L, 24 V	B2L, 12 V	B4L, 12 V
1a	1	1	Heat exchanger incl. screws, and thermal separation	25.2953.99.0601	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
1b				25.2955.99.0601																						
			combustion chamber	25.2959.99.0601																						
				25.3020.06.0000																						
2a	1	1	Combustion chamber incl. screws, blower seal, and thermal separation	20.2029.99.1000	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
				25.2953.99.1000																						
			and thermal separation	20.2030.99.1000																						
			combustion chamber	25.2955.99.1000																						
2b				25.2959.99.1000																						
				25.3020.10.0000																						
3a	1	1	Blower 12 V incl. screws and blower seal	25.2953.99.1500	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
				25.2955.99.1500																						
				25.2957.99.1500																						
3b				25.2959.99.1500																						
3a			Blower 24 V incl. screws and blower seal	25.2954.99.1500																						
				25.2956.99.1500																						
				25.2958.99.1500																						
3b				25.2960.99.1500																						
				25.3020.99.1500																						
4a	1	1	Blower seal incl. blower screws, srews for combustion chamber and thermal separation	25.2953.99.0603	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
				25.2955.99.0603																						
4b			combustion chamber	25.2959.99.0603																						
5	1	1	Control box 12 V incl. screws	20.2029.99.5000	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
				25.2953.99.5000																						
				25.3092.99.5000																						
				25.3034.99.5000																						
				20.2030.99.5000																						
				20.2031.99.5000																						
				25.2955.99.5000																						
				25.2957.99.5000																						
				25.3035.99.5000																						
				25.3036.99.5000																						
				25.2959.99.5000																						
				25.3037.99.5000																						
				25.3051.99.5000																						
			Control box 24 V incl. screws	25.2954.99.5000																						
				25.3038.99.5000																						
				25.2956.99.5000																						
				25.2958.99.5000																						
				25.3039.99.5000																						
				25.2960.99.5000																						
				25.3020.99.5000																						

Item No.	Quantity per unit	Quantity per SU	Designation	Order No. (SU)	For unit																								
					D2L, 12V	D2L, 12V	D2L, 12V CI	D2L, 12V CI	D2L, 12V VDP	D2L, 24V	D2L, 24V ADR	D4L, 12V	D4L, 12V VDP	D4L, 24V	D4L, 24V ADR	D4R, 12V	D4R, 12V VDP	D4R, 12V CI	D4R, 12V CI	D4R, 24V	D6L, 12V	D6L, 12V VDP	D6L, 24V	D8L, 24V	B2L, 12V	B4L, 12V	B4R, 12V		
6	1	1	Cable harness heater	25.2953.99.0102	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
				25.2959.99.0102																									
7	1	1	Jacket shell, top	25.2953.01.0101	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
				25.2955.01.0101																									
				25.2959.01.0101																									
8	1	1	Grommet, cable outlet	25.2069.00.0001	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
9	1	1	Jacket shell, bottom	25.2953.01.0102	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
				25.2955.01.0102																									
				25.2959.01.0102																									
10	1	1	Seal, flange	25.2953.01.0003	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
				25.2959.01.0003																									
				25.3020.01.0003																									
11	1	1	Combination sensor (incl. air inlet sensor and installation tool)	25.2953.99.4000	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
				25.2959.99.4000																									
12	1	1 V	Glow plug with grommet	12 V 20.2029.99.0104	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
				24 V 25.2954.99.0104																									
13	1	1	Heat exchanger base, flange plate incl. screws	25.2959.99.0104																									
				25.3020.01.0004																									

3 Electrics, fuel, hot air and combustion air system

3.1 Spare parts diagram

3.1.1 Airtronic M3



Item No.	Quantity per unit	Quantity per SU	Designation	Order No. (SU)	For unit																							
					D2L, 12V	D2L, 12V	D2L, 12V CI	D2L, 12V CI	D2L, 12V VDP	D2L, 24V	D2L, 24V ADR	D4L, 12V	D4L, 12V VDP	D4L, 24V	D4L, 24V ADR	D4R, 12V	D4R, 12V VDP	D4R, 12V CI	D4R, 12V CI	D4R, 24V	D6L, 12V	D6L, 12V VDP	D6L, 24V	D8L, 24V	B2L, 12V	B4L, 12V	B4R, 12V	
16	1	1	Connection socket Ø 60 mm	22.1000.01.0035																								
			Ø 90 mm	22.1000.01.0037	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
			Ø 75 mm	22.1000.01.0036	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
17	1	10	Pipe clip	152.10.069																			•					
18	1	1	Grille Ø 60 mm	25.1688.80.0600	•	•	•	•	•	•	•													•				
			Ø 75 mm	25.1552.05.0100									•	•	•	•	•	•	•	•	•	•	•			•	•	
			Ø 90 mm	25.1729.80.0001																					•	•	•	•
19	1	1	Hood Ø 60 mm	22.1000.01.0016	•	•	•	•	•	•	•														•			
			Ø 90 mm	22.1000.01.0019										•	•	•	•	•	•	•	•	•	•			•	•	
			Ø 75 mm	22.1000.01.0017	•	•	•	•	•	•	•	•														•	•	•
			Ø 75 mm	22.1000.01.0018										•	•	•	•	•	•	•	•	•	•	•			•	•
			Ø 90 mm	22.1000.01.0086																							•	•
			Ø 100 mm	22.1000.01.0087																							•	•
20	1	1	Flexible pipe Ø 60 mm	10.2114.31.0000	•	•	•	•	•	•	•														•			
			Ø 90 mm	10.2114.37.0000										•	•	•	•	•	•	•	•	•	•			•	•	
			Ø 75 mm	10.2114.34.0000	•	•	•	•	•	•	•	•														•	•	•
			Ø 100 mm	10.2114.38.0000																							•	•
21a	1	1	Exhaust silencer	25.1864.81.0100	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
21b		25.1806.80.0100																						•	•	•		
22	1	1	Cable harness heater	25.2720.80.1100	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
23	1	1	Bracket exhaust silencer, Z shape	20.1533.88.0007	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
			Bracket exhaust silencer, L shape	20.1348.03.0004	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
24	3	10	Pipe clip exhaust	22.1000.51.4400	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	
				22.1000.51.4500																							•	•
25	1	1	Exhaust pipe with end sleeve, flexible																									
			di = 24 mm, L = 300 mm	20.1731.80.0400	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
			di = 30 mm, L = 1300 mm	22.1000.40.6500																							•	•
26	2	100	Grommet	20.1280.09.0103	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
27	1	1	End sleeve, combustion air	25.1729.89.0002	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
28	1	10	Hose clip Ø 20 – 32 mm	10.2067.02.0032	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
29	8	100	Hose clip Ø 9 mm	10.2068.00.9098	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
30	1	1	Hose di = 3.5 / 3 mm	360.75.300	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
31	1	1	Fuse holder, complete set	22.1000.31.0600	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
32a	1	1	Connection housing kit, metering pump	22.9000.30.0411	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
32b			Adapter cable, metering pump	22.9000.30.0417																				•	•	•		
33	1	1	Pot-type strainer, metering pump	20.1312.00.0006	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	

Eberspächer Climate Control
Systems International GmbH
Eberspächerstraße 24
73730 Esslingen
Germany
info@eberspaecher.com
www.eberspaecher.com

